

PPP to Ethernet Type I Interworking RAM Package Release 0.0.0

General

This release note reflects differences between the *QUICC Engine™ Block Reference Manual with Protocol Interworking*, QEIWRM, Rev 3, and the features which are available for this device using the provided microcode RAM packages. The following release note reveals any exceptions to the features which are specified in this release of the specification. The notes describe any addition to the specification or any missing functionality in comparison to the specification.

The user should follow tightly the instructions specified in the `QE_Ucode_Loader` file provided in the package in relation to the header files containing the code. These instructions assure proper operation and activation of the right features in the code.

Refer to the *QUICC Engine Microcode Errata* for all known issues related to this and other microcode packages.

This package includes the following core blocks: MLMC PPP, Ethernet, Interworking, IP Reassembly, IEEE Std. 1588™ and IP Header Compression support. Features of these core blocks that are not supported in this package are described in [Table 3](#).

Availability

The package is currently available for the following devices.

Table 1. Package Availability by Device

Device	Loader file name (.h)
MPC8360 rev 2.1	iw_pe_type_e_mpc8360_r2.1.h
MPC8568 rev 1.1	iw_pe_type_e_mpc8568_r1.1.h

Package Content

The tables below designate the content of this package. The baseline is the *QUICC Engine™ Block Reference Manual with Protocol Interworking, QEIWRM, Rev 3*. The tables designate additional features and features which are not supported. For the specification of additional features, which are not described in the *QUICC Engine™ Block Reference Manual with Protocol Interworking, QEIWRM, Rev 3*, please contact Freescale support. Contact information may be found at www.freescale.com.

Table 2. New Features (Which are not Described in QEIWRM, Rev 3)

Feature	Comments
None	

Table 3. Removed Features (Described in QEIWRM, Rev 3 but Not Supported)

Feature	Comments	QEIWRM, Rev 3
Header manipulation in termination mode Insert/remove/replace VLAN	REMODER[VTagOP] and REMODER[VNonTagOP] (in RxGPRAM) are not supported.	Section 8.5.3.9, "Rx Ethernet Mode Register (REMODER)"
	TAD[VTagOP] and TAD[VNonTagOP] are not supported.	Section 8.6.2.6.5, "Termination Action Descriptor (TAD)"
LPM PCD		Section 30.3.2.4, "Longest Prefix Match (LPM) PCD"
Expanded Hash Table		Section 30.5.3.3.1, "TableLookup_FourWayHash PCD"
VLAN Specific Header Manipulation Command Descriptor		Section 31.1.11.2, "VLAN Specific Header Manipulation Command Descriptor"
CAM Emulation Lookup Table (CELUT) for LookupKey Size of 2 Bytes		Section 30.5.3.1.1, "CAM Emulation Lookup Table (CELUT) for LookupKey Size of 2 Bytes"

Table 3. Removed Features (Described in QEIWRM, Rev 3 but Not Supported) (continued)

Feature	Comments	QEIWRM, Rev 3
IP Header Compression Over Ethernet Links		Section 31.1.11.18, "Ethernet IP/UDP Header Decompression Command Descriptor (HDCD)," Section 34.4.1.1.2, "Compression of Frames Transmitted on Ethernet Links," and Section 34.4.2.2, "Decompression of PPPoE Frames Received on Ethernet Links"
IP-Only Header Compression	Compression Type 0x02 not supported.	Chapter 34, "IPv4/UDP Header Compression"
Hierarchical Scheduler		Section 8.4.17, "Hierarchical Scheduling Support"
PPP Mux		Section 25.9, "PPP Mux Process"
IP fragmentation	Tx Global Parameter RAM TEMODER bit 8 is not supported.	Section 8.5.3.3, "Tx Global Parameter RAM"

Revision History

Table 4. Revision History for Release 0.0.0

Release Date: Sept 30, 2009 Revision Register Number: 0xBBE01000	
New Features	None. Initial Release.
Removed Features	None. Initial Release.
Bug Fixes	None. Initial Release.

How to Reach Us:

Home Page:

www.freescale.com

Web Support:

<http://www.freescale.com/support>

USA/Europe or Locations Not Listed:

Freescale Semiconductor, Inc.
 Technical Information Center, EL516
 2100 East Elliot Road
 Tempe, Arizona 85284
 1-800-521-6274 or
 +1-480-768-2130
www.freescale.com/support

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
 Technical Information Center
 Schatzbogen 7
 81829 Muenchen, Germany
 +44 1296 380 456 (English)
 +46 8 52200080 (English)
 +49 89 92103 559 (German)
 +33 1 69 35 48 48 (French)
www.freescale.com/support

Japan:

Freescale Semiconductor Japan Ltd.
 Headquarters
 ARCO Tower 15F
 1-8-1, Shimo-Meguro, Meguro-ku
 Tokyo 153-0064
 Japan
 0120 191014 or
 +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor China Ltd.
 Exchange Building 23F
 No. 118 Jianguo Road
 Chaoyang District
 Beijing 100022
 China
 +86 10 5879 8000
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor
 Literature Distribution Center
 1-800 441-2447 or
 +1-303-675-2140
 Fax: +1-303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

Freescale and the Freescale logo are trademarks or registered trademarks of Freescale Semiconductor, Inc. in the U.S. and other countries. All other product or service names are the property of their respective owners. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org. IEEE 1588 is a registered trademarks of the Institute of Electrical and Electronics Engineers, Inc. (IEEE). This product is not endorsed or approved by the IEEE.

© Freescale Semiconductor, Inc., 2009-2010. All rights reserved.

